

ELEKTROSVIT



LVS

reference list



0,4kV
1250A



0,8kV
1250A



0,4kV
1250A



0,4kV
1000 A



0,4kV
1250 A



0,8kV
1000 A



0,4kV
1250A



0,4kV
1250A




0,4kV
1600A



QF1
Main switch
0.8 kV



0,8kV
2000A



0,4kV
1000 A



0,4kV
1250A



0,8kV
1250A